




Scan this QR code for **video instructions** – choose from a quick overview or a detailed installation guide.




Hold the **cover** with one hand. With the other hand, gently squeeze the **adjustment tabs** on both sides and fully extend the **back piece**.



Tilt the unit diagonally and weave the **pick-up wings** under the strings above the sound hole, ensuring each string is properly seated on a **pick-up wing**.



Gently pull the unit backwards until the **pick-up wings** contact the guitar's saddle. Then carefully lower the unit to a position parallel to, but not touching, the soundboard.



Squeeze the **adjustment tabs** and push the **back piece** to the guitar's tail, while retracting the **cover** with your other hand to expose the **pick-up bar** and its **three arms** slightly.



Firmly press the **pick-up wings** to ensure they are fully in contact with the saddle.



Ensure the **suspension springs** are aligned with the **pick-up arms**. If not, gently adjust the unit from the **back piece** to correctly align the **suspension springs**.



To remove, gently pull the **back piece**. Lift the unit, move it toward the sound hole, and then carefully weave it out from under the strings.